

# Remote Set Up

## Pair the TV, DVD, VCR or Audio to the Cobalt TV® Remote

1. Manually turn ON the device that you want to setup on the remote
2. Press and Hold <<SETUP>> until the mode key blinks twice
3. Press and release the mode key for device you wish to setup. The mode key stays lit.
4. Find your device and brand from the charts below and note the DIGIT key assigned to your brand. Press and hold down the DIGIT key for your device/brand while pointing the remote to the device.
5. Let go of the key when your device turns OFF. Setup for that device is complete.

	TV
Digit	Brand
1	Insignia
2	LG
3	Panasonic
4	Philips Magnavox
5	Samsung
6	Sanyo
7	Sharp
8	Sony
9	Vizio
0	Westinghouse

	DVD/VCR
Digit	Brand
1	Insignia
2	LG
3	Panasonic
4	Philips Magnavox
5	RCA
6	Samsung
7	Sharp
8	Sony
9	Toshiba
0	Vizio

	Audio
Digit	Brand
1	Bose
2	Denon
3	LG
4	Onkyo
5	Panasonic
6	Philips
7	Pioneer
8	Samsung
9	Sony
0	Yamaha

### Searching for Your Code

If your home entertainment device does not respond to the Universal Remote Control after trying all of the codes listed for your brand, or if your brand is not listed at all, try searching for your code. To search:

1. Turn on your TV.
2. On the remote control, press TV once; it will blink once. Then press and hold SETUP until the TV key blinks twice.
3. Enter 991. The TV key will blink twice. Aim the remote control at the TV and press POWER once.
4. Press and release the CH+ key continuously, then stop when the TV turns off.
5. Press POWER. The TV should turn on, then press SETUP once to lock in the code. The LED will blink twice to indicate that the code is saved. NOTE: If the TV does not turn on during step 5, then slowly press and release CH- to go back through the codes, then press SETUP when the TV turns on.

To search for the codes of your other devices, repeat steps 1 through 5, but substitute the appropriate key (e.g., VCR, DVD, AUD, or STB) for the device you are searching for.

### Setting Up to Power On/Off the both Set Top Box and the TV with the one push of the remote POWER button.

1. Press and hold "SETUP" until Set Top Box or the TV button on the remote flashes twice .
2. Enter "995", then press "POWER" once.
3. Press "STB" once, then "TV" once, (if customer wants to shut off AUD, DVD, VCR then press those also.
4. Then press and hold "SETUP" until it flashes twice.

Press POWER and if the remote is programmed for the specific TV, the TV will shut off. Pressing POWER again will turn on the TV and Set Top Box. The remote will control both the TV and Set Top Box.



Provided by

